FIX-A-LOO



HYGENİX

DELUXE

SOFT CLOSE TOILET SEAT

CODE: 235381

10 YEAR WARRANTY

This warranty runs for ten years from the date of purchase.

Our products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other loss or damage. You are also entitled to have the goods repaired if the goods fail to be of an acceptable quality and the failure does not amount to a major failure.

What is covered:

This warranty covers the product for domestic use only. The warranty covers any defects in materials or workmanship with the exception of the reasons stated below.

What is not covered:

This warranty does not cover wear and tear to working parts, misuse or abuse. It does not cover discolourations due to exposure or cleaning chemicals.

Claim procedure:

If you believe you have a legitimate claim, please contact FIX-A-TAP Australia via our website at www.fixatap.com.au/warranty to complete the warranty claim form. Alternatively you can contact our office on 02 9476 7400.

Any written correspondence should be sent to:

FIX-A-TAP Australia Pty Ltd, PO Box 200, Wahroonga NSW 2076

Please keep your receipt for proof of purchase.

PLUMBCONNECT PLUMBERS REGISTRY


Need a plumber?

To find a plumber in your area, consult our PlumbConnect Registry using the QR code or via our website:



www.fixatap.com.au/find-a-plumber


INSTALLATION INSTRUCTIONS



1. Attach rubber base to hinge ensuring that the holes line up.




2. Assemble the pieces as shown. The bolt goes through the hinge and base with the rod pointing upwards, then through the toggle (ensure the pointed side is pointing downwards so that it will slip flat when threaded through the pan hole). The nut is added last with the flat side facing upwards.




3. On blind fixing pans, slide the nut, toggle and the bolt through the pan hole. Pull up the hinge base so that the toggle is pulling against the bottom of the pan. Tighten the screws from above, turning clockwise with a Phillips head screwdriver.

If bottom fixing, the toggle and nut can be affixed from below.



4. Position the locking rods to line up with the seat holes. Click the seat firmly onto the rods. Shut seat and adjust the seat position to the desired location.

If bottom fixing, tighten nuts firmly from below.



5. Keeping the hinges in your desired location, remove seat by pressing the 'quick release' button.

If top fixing, tighten bolts from above using a screwdriver.

Add stainless steel hinge covers, then replace



Clean with warm soapy water or a household detergent using a soft cloth or sponge. Do not use bleach or a harsh chemical based cleaner. Do not use a scourer as this may damage the finish.