

# FIX-A-LOO



## 5 YEAR WARRANTY

**This warranty runs for five years from the date of purchase.**

Our products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other loss or damage. You are also entitled to have the goods repaired if the goods fail to be of an acceptable quality and the failure does not amount to a major failure.

#### What is covered:

This warranty covers the product for domestic use only. The warranty covers any defects in materials or workmanship with the exception of the reasons stated below.

#### What is not covered:

This warranty does not cover wear and tear to working parts, misuse or abuse. It does not cover discolourations due to exposure or cleaning chemicals.

#### Claim procedure:

If you believe you have a legitimate claim, please contact FIX-A-TAP Australia via our website at [www.fixatap.com.au/warranty](http://www.fixatap.com.au/warranty) to complete the warranty claim form. Alternatively you can contact our office on 02 9476 7400.

#### Any written correspondence should be sent to:

FIX-A-TAP Australia Pty Ltd,  
PO Box 200,  
Wahroonga NSW 2076

Please keep your receipt for proof of purchase.

## PLUMBCONNECT PLUMBERS REGISTRY

#### Need a plumber?

To find a plumber in your area, consult our PlumbConnect Registry using the QR code or via our website:

[www.fixatap.com.au/find-a-plumber](http://www.fixatap.com.au/find-a-plumber)



**FIX-A-TAP® AUSTRALIA PTY LTD**  
The Ultimate Plumbing Solution  
PO Box 200 Wahroonga NSW 2076  
[www.fixatap.com.au](http://www.fixatap.com.au)  
Made in China  
© 2021 FIX-A-TAP



# HYGENIX®

## SOFT CLOSE TOILET SEAT

CODE: 253231

## INSTALLATION INSTRUCTIONS



1a. Squeeze red locking clips towards each other to release seat.

1b. Slide hinge frame away from the seat.

2a. Place the white rectangular supports inside the frame holes as shown. Supports can slide to adjust seat position.

2b. Place the metal rectangular washers inside the white supports.

3. (Skip this step for bottom fixing.) If you would like to top fix the seat, push the nuts through your pan holes with the wider flat side up. The spherical design holds the nut firmly from underneath the pan.

4. Place the frame with the metal washers over the pan holes. If top fixing, fasten the bolts to the rubber nuts using a screwdriver. If bottom fixing, attach the white washers and nuts to the bolts via the underside of the pan holes.

5. Slide seat onto hinge until the red locking clips click outwards. If position is incorrect, press the red locking clips towards the centre, remove seat, loosen bolts and slide the frame on the supports to the desired position before retightening.

## MAINTENANCE CLEANING INSTRUCTIONS

Clean with warm soapy water or a household detergent using a soft cloth or sponge. Do not use bleach or a harsh chemical based cleaner. Do not use a scourer as this may damage the finish.