


EASY INSTALLATION

1. Turn off water at mains.
2. Remove lever handle.
3. Unscrew dome cover & locking nut.
4. Replace cartridge ensuring pins lock in correctly.
5. Reassemble tap.
6. Turn on water supply & inspect for leaks.



FIX-A-TAP®

AUSTRALIA PTY LTD

The Ultimate Plumbing Solution

PO Box 200 Wahroonga

NSW 2076 Australia

Made in Taiwan ©2023

www.fixatap.com.au

*Visit our website for
socials, plumbers,
product info & more*

#240101