

# EASY INSTALLATION

Handle



Flange



Bonnet



Spindle



O-Ring



Washer



Tap Valve



1. Turn off water at mains.
2. Remove tap handle; unscrew & remove spindle assembly.
3. Replace tap valve, fibre body washer, & o-ring.
4. Reassemble spindle & handle.
5. Turn on water supply and inspect for leaks.

## HANDY HINT

Apply FIX-A-TAP waterproof lubricant to o-ring and spindle (Product #217271).

**FIX-A-TAP®**

**AUSTRALIA PTY LTD**

*The Ultimate Plumbing Solution*

PO Box 200 Wahroonga

NSW 2076 Australia

Made in Australia ©2023

[www.fixatap.com.au](http://www.fixatap.com.au)

*Visit our website for  
socials, plumbers,  
product info & more*